



**WIRELESS COMMUNICATION SYSTEM
WACO WM868**

WM868-SI4-LP-H

Revision 2.0

Contents

1	Introduction	1
1.1	WACO communication system	1
1.2	Module usage	1
2	Technical parameters overview	3
3	Configuration of the WM868-SI4-LP-H module	4
3.1	Configuration of the module with using of the configuration cable	4
3.1.1	Connecting of module to computer	4
3.1.2	Using of „PuTTY” freeware program for configuration	5
3.1.3	General rules for configuration of the module by configuration cable	6
3.2	Configuration of the module via radio	6
3.2.1	Using of „RFAN 3.x” program for the module configuration via radio	6
3.2.2	Connection of WACO communication GateWay to computer	7
3.2.3	General rules for configuration via radio	7
3.2.4	Remote configuration with using of RFAN 3.x Analyzer in steps	8
3.3	USB-CMOS converter driver installation	9
3.4	„USB GateWay” and „USB-IRDA” driver installation	10
3.4.1	How to disable driver signature enforcement in Windows 8 system	11
3.4.2	How to disable driver signature enforcement in Windows 10 system	12
3.4.3	Support of older OS Windows versions and OS Linux support	12
3.5	Setting of WM868-SI4-LP-H module parameters by configuration cable	13
3.5.1	List of WM868-SI4-LP-H module configuration parameters and commands	13
3.5.2	„Configuration” group of commands for writing of configuration and reset	14
3.5.3	Commands for settings of radio-frequency subsystem	15
3.5.4	Time constants and number of repetitions	17
3.5.5	Commands for setting of input counters	18
3.5.6	Setting of test broadcasting	19
3.5.7	Special commands for module activation and diagnostics	19
3.5.8	Module current status statement	20
3.6	Setting of WM868-SI4-LP-H module parameters via radio	20
3.6.1	Module description and identification parameters	20
3.6.2	Setting of the module System Time	21
3.6.3	Uptime, configuration status and reset cause parameters	21
3.6.4	Parameters „Input value”, „Temperature” and „Voltage”	22
3.6.5	„SISA TimeOuts” Parameters	22
3.6.6	Radio-frequency subsystem parameters	23
3.6.7	„SLRF Test flag” and „SLRF Test timeout” parameters	24
3.6.8	„Sequence #” parameter	25
3.6.9	List of all variables displayed by ”WALK” command	25
3.6.10	Overview of module configuration parameters	26
3.7	Structure of module data messages	27
4	Operational conditions	29
4.1	General Operation Risks	29
4.1.1	Risk of mechanical and/or electric damage	29
4.1.2	Risk of premature battery discharge	29
4.1.3	Risk of damage by excessive humidity	29
4.2	The condition of modules on delivery	30
4.3	Modules storage	30
4.4	Safety precautions	30
4.5	Environmental protection and recycling	30
4.6	WM868-SI4-LP-H module installation	30
4.7	Module and meter replacement	32
4.8	Module dismantling	33
4.9	Functional check of the module	33
4.10	Operation of the WM868-SI4-LP-H module	33

5	Troubleshooting	34
5.1	Possible causes of module failures	34
5.1.1	Power supplying failures	34
5.1.2	System failures	34
5.1.3	Failures of communication with meters	34
5.1.4	Transmitter and receiver failures	35
5.2	Troubleshooting procedure	36
6	Additional information	37

List of Tables

1	Overview of WM868-SI4-LP-H module technical parameters	3
2	Overview of WM868-SI4-LP-H module configuration parameters	26

List of Figures

1	Principle of data transfer from the WM868-SI4-LP-H module	2
2	View of the WM868-SI4-LP-H module	2
3	Appearance of the USB-CMOS converter in Windows „Device Manager”	4
4	Configuration via USB port of computer	5
5	Terminal setting for serial line communication	5
6	Open terminal window for module configuration via serial line	6
7	Principle of local configuration via radio	6
8	Principle of remote configuration via radio	7
9	Appearance of WACO USB GateWay in the MS Windows „Device Manager”	7
10	Entering of devices and variables into the remote configuration window	8
11	Progress of getting values of preselected variables of the module by using of „GET” command	9
12	Appearance of converter without driver in the Windows „Device Manager” table	10
13	Displaying of the device without driver in ”Device Manager” window	10
14	Manual selection of the driver file from a folder	11
15	USB driver installation	11
16	Setting of module System Time via radio	21
17	Current status of „SLRF My Address” and „SLRF Group Address”	24
18	List of all WM868-SI4-LP-H module variables displayed by RFAN 3.x analyzer	25
19	WACO SLRF protocol structure	27
20	Structure of WACO system data packet	27
21	Preview of „NEP coding table” for coding of variables in WACO system	28
22	View of WM868-SI4-LP-H module INFO message received by RFAN 3.x analyzer	28
23	Detailed view of the WM868-SI4-LP-H module	31

1 Introduction

This document describes features, parameters and setting possibilities of the WM868-SI4-LP-H module, which is used for reading of consumption meters or sensors with pulse output (water meters, electrometers, gas-meters. . .) and for radio-broadcasting of the data from connected meters/sensors through the WACO radio-frequency network

1.1 WACO communication system

WACO (Wireless Automatic Collector) is radio frequency (RF) communication system intended especially for the remote reading of consumption meters (smart metering area), automatic data collection from sensors (telemetry area), and bi-directional data transfer among control, sensing and actuating elements in automatic control systems (industrial automation area). Installed WACO radio-frequency elements create local radio network covering object of interest (flat, house, building, compound...) or required area (street, city...).

WACO RF network has a „mesh” type of topology, where in reach of each radio element there could be placed several other network elements that could operate also as repeaters of received signal. In this kind of network there are typically several possible communication paths between the central point and other single elements of the network. WACO network communication protocol was designed to provide a **maximum data transmission reliability and redundancy** with using of multiple communication paths, but at the same time the network is protected against circularity and multiplication of messages by sophisticated algorithms so that the network keeps also a **high performance** even with high number of radio elements working in one network.

WACO communication protocol was designed in compliance with a telecommunication standard **ISO/OSI model** that ensures a high variability of supported applications.

WACO radio-frequency devices (hereinafter „radio modules”) are equipped with **various types of input/output interfaces** that enables integration of various connected device (meters, sensors, actors...) into one network.

WACO communication system includes also special communication devices - **WACO GateWays**, that enable receiving of radio messages from the local WACO RF-network and transfer them to the local or remote computer through the serial line or Internet and (in inverse direction) receiving messages from the serial line/Internet and broadcast them into „its” RF-network.

1.2 Module usage

The WM868-SI4-LP-H module can be used for remote reading of consumption meters or sensors (e.g. water meters, electrometers, gas-meters. . .), that are equipped with standard pulse output („SI” type) commonly used in the metering area. The module is equipped by four inputs of SI type and up to four meters of different kind, with different initial values can be connected to these inputs. The module continuously registers incoming pulses (generated by meters) into its internal counters and broadcasts current statuses of all connected meters as WACO standard radio-messages („INFO-messages”) either automatically (with preset broadcasting period) or on demand (with using of „Wake-On-Radio” function). Each INFO-message contains readings of connected meters as well as module system time, battery voltage and processor temperature. INFO messages are transmitted with general „broadcast” address and with application („port”) number 37 („SISA_TX” application), where a confirmation of received message by addressee is not required.

Broadcasted messages are transferred through the WACO RF network to the local **communication gateway** of WM868-RFU (WACO USB GateWay), WM868-RFE (WACO Ethernet GateWay), or WM868-RFG (WACO GSM GateWay), type, where they are converted to the format which is suitable for either serial line transfer (WM868-RFU), or for the transfer through the Ethernet/IP network (WM868-RFE), or transfer through the GSM/GPRS services (WM868-RFG). The messages are transferred to the local or remote computer, where they are decoded and processed. The computer must be equipped by coding/decoding program for processing of WACO protocol (so called „WACO Driver”). In reverse direction (from central computer to meter) the messages are transferred analogously, the communication gateway performs their conversion to the radio-frequency format and broadcasting to the RF network. Principle of data transfer from the WM868-SI4-LP-H module through the WM868-RFE communication gateway is shown in the upper part of figure 1.

Alternatively, the messages of the WM868-SI4-LP-H module with readings from connected meters can be received by local „**collecting unit**” of the WACO system. The „collecting unit” is a special WACO RF-module intended for collecting of the data from battery powered WACO modules, conversion of their data into standard M-Bus protocol and their further transfer to the M-Bus master through the physical or virtual bus. Principle of data transfer from the WM868-SI4-LP-H module through the WACO collection unit of WM868-SJ-MS type is shown in the lower part of the figure 1.




Figure 1: Principle of data transfer from the WM868-SI4-LP-H module

The WM868-SI4-LP-H module supports „Wake-On-Radio” (WOR) function that enables raising of communication „on demand” even in time of module’s „hibernation. The module can be switched to active state by receiving of special radio message („WOR-packet”) and by follow-up query the actual readings can be immediately obtained from the module. This function can be used either for immediate gathering of data with using of „walk-by” reading system, or for remote diagnostics and configuration of the module via radio (see chapter 3.2 „Configuration of the module via radio”).

The module is enclosed in humidity-proof plastic casing and can be used in interiors as well as in exteriors. The module is power supplied by internal battery with capacity of 7 Ah, the lifetime is up to 10 years for 60 minutes broadcasting period. Battery lifetime can be negatively influenced by shorter broadcasting period, or by storing and operation in sites with the temperatures exceeding the recommended range, or operation in area with permanent external disturbance or with dense radio-frequency traffic.

External appearance of the WM868-SI4-LP-H module is shown in the figure 2.



Figure 2: View of the WM868-SI4-LP-H module

2 Technical parameters overview

Overview of WM868-SI4-LP-H module technical parameters is shown in the Table 1 below.

Table 1: Overview of WM868-SI4-LP-H module technical parameters

RF subsystem parameters		
Frequency band	868,0 až 868,6	MHz
Modulation	FSK	
Number of channels	3	
Bandwidth	200	kHz
Transmitting power	25	mW
Receiver sensitivity	106	dBm
Communication protocol	WACO	
Transmission speed	38400	Baud
Antenna connector	SMA female	
Antenna characteristic impedance	50	Ω
Configuration interface RS232		
Transmission speed	9600	Baud
Operation mode	asynchronous	
Transmission parameters	8 data bits, 1 stop bit, none parity	
Signal level	TTL/CMOS	
Pulse/sensor inputs		
Resistance of released contact	more than 10	$M\Omega$
Resistance of short-circuited contact	less than 10	$k\Omega$
Maximum frequency of input pulses	300	Hz
Minimum pulse length	20	ms
Power supplying		
Lithium battery voltage	3,6	V
Lithium battery capacity	7	Ah
Weight and dimensions		
Length	145	mm
Width	45	mm
Height	100	mm
Weight	cca 300	g
Storage and installation conditions		
Installation environment (by ČSN 33 2000-3)	normal AA6, AB4, A4	
Operation temperature range	(-20 ÷ 40)	$^{\circ}\text{C}$
Storage temperature range	(0 ÷ 40)	$^{\circ}\text{C}$
Relative humidity	95	% (w/o condensation)
Degree of protection	IP65	

3 Configuration of the WM868-SI4-LP-H module

Configuration parameters of the WM868-SI4-LP-H module can be displayed and changed from the common computer (PC) by one of these methods:

- with using of „USB-CMOS” converter and configuration cable connected to the module
- wireless, with using of radio-frequency communication gateway

Technique of interconnection of the module with configuration computer and general rules of configuration are described in detail in the section 3.1 „Configuration of the module with using of the configuration cable”. The description and meaning of all configuration parameters that can be checked and changed by cable can be found in the section 3.5 „Setting of WM868-SI4-LP-H parameters via configuration cable”. Description of interconnection of the radio-communication gateway with computer and general rules of configuration **via radio** are described in the section 3.2 „Configuration of the module via radio”. The description and meaning of the parameters that can be changed via radio can be found in the section 3.6 „Setting of WM868-SI4-LP-H parameters via radio”.

3.1 Configuration of the module with using of the configuration cable

Configuration of the module can be performed by using of any PC with MS Windows or Linux operating systems interconnected by configuration data cable. The module’s communication interface is of RS-232 (COM) type with CMOS signal level. The ”CONFIG CMOS” configuration connector is placed on the module’s printed circuit board.

3.1.1 Connecting of module to computer

Configuration can be performed by using of common USB port of the computer. For the interconnection with a USB port of computer it is necessary to use an manufacturer’s original configuration cable with „USB-CMOS” converter (see Figure 4). This converter creates a virtual serial port through the USB interface and adapts voltage levels of the module’s configuration port to the standard USB port of common PC. So as to be able to create a virtual serial connection via USB interface, there must be a relevant driver installed in the computer operation system. After the „USB-CMOS” converter is connected to computer for the first time, operating system will find and install appropriate generic driver of „USB Serial Device” category automatically. After driver installation is completed, the device will appear in the „Ports (COM and LPT)” section of the „Device Manger” window as „USB Serial Device (COMx)” (see figure 3).




Figure 3: Appearance of the USB-CMOS converter in Windows „Device Manager”

As some of the older MS Windows versions do not support a generic driver for USB serial ports, the automatic installation of the driver could fail (system reports „Driver software installation failure”, or „driver not found“). In this case there is necessary to install the driver manually, following the steps in paragraph 3.3 „Installation of USB-CMOS converter driver”.

Insert USB-CMOS converter to the USB port of computer. Open module’s casing to enable access to the configuration connector. Connect configuration cable to the „CONFIG CMOS” port on the module’s printed circuit board. Thus the computer is connected with the module and ready for performing any changes in configuration (see figure 4 „Configuration via USB port of computer”).



Figure 4: Configuration via USB port of computer

3.1.2 Using of „PuTTY” freeware program for configuration

The module configuration can be done with using of any suitable program for the serial line communication. The description bellow is relevant for the open-source software „PuTTY” that is available for free on www.putty.org.




Figure 5: Terminal setting for serial line communication

„PuTTY” software runs after clicking on the downloaded file „putty.exe“. There will open a window of the terminal communication (see Figure 5). For switching the program into the serial line communication, choose „Serial” option of the connection type in the „Session” tab.

Check (or set up) the communication speed („Speed”) to 9600 bits/s and then enter into the „Serial line“ tab the number of the serial port that the system automatically assigned to the virtual port at the moment of interconnection module to the computer. The number of the serial port can be found in OS Windows by using of „Device Manager” (Control Panel/System and Maintenance/Device manager) by clicking on „Ports (COM a LPT)” where the numbers of ports appear (e.g. „COM23” - see figure 3).

Click on „Open” button in „PuTTY” program and open the terminal window. After pressing of „ENTER” key there will appear a command prompt „si4h” which announces that the module is ready to be configured (see figure 6).




Figure 6: Open terminal window for module configuration via serial line

3.1.3 General rules for configuration of the module by configuration cable

Activate the terminal window for the configuration via the configuration cable according to the instructions above. These general rules are valid for entering commands in the command line:

- the command must be entered only when a prompt for command appears in front of the cursor mark (colored or flashing little square); the prompt is either „si4h” or „mon” format (see figure 6);
- it is possible to enter only one command each time;
- the command could be entered in an alphanumeric character (or several characters);
- the command is sent to device by clicking on „ENTER” key. After the command being carried out, the prompt will appear again and it is ready for a new command to be entered. In case the command fails to execute, there will appear an error report;
- check the execution of the command by displaying of the list of configuration parameters which appears by entering ”show” or ”/” and pressing on „ENTER” key;
- to display a summary of configuration commands and their parameters („HELP”), enter ”?” (question mark), or ”/?” and press „ENTER” key;
- when entering characters, distinguish strictly the capital and small letters (according to the documentation or „HELP”);
- Do not enter other characters than those listed in „HELP“ or in the documentation, otherwise you would be risking the unwanted command enter that might be the same as the ones used for manufacturer settings, diagnostics or service and repair.

3.2 Configuration of the module via radio

Remote configuration via radio signal is proceeded via special WACO radio messages (queries and commands) that will query the module to get current settings of its individual parameters, or (in case of need) will send a command to change these parameters.

It is possible to configure the module locally from the convenient spot within module radio range (for example from PC with connected gateway WM868-RFU - see figure 7), or to configure the module remotely from a remote computer via local gateway WM868-RFE (WACO Ethernet Gateway) or WM868-RFG (WACO GSM Gateway) as depicted in the figure 8.




Figure 7: Principle of local configuration via radio

In both cases there must be direct radio visibility between the configured module and the communication gateway – it is totally **impossible to configure the WM868-SI2/SI2-H modules via repeater**.

3.2.1 Using of „RFAN 3.x” program for the module configuration via radio

The universal tool for the configuration of WACO family modules is „WACO Radiofrequency Analyzer RFAN 3.x” (hereinafter „analyzer”) that can be used for setting up of all remotely configurable parameters of the module. Analyzer is a computer program written in Java language, which can be installed to any common PC (desktop, laptop, tablet...) with operating system with Java Virtual Machine support. Functionality of RFAN 3.x analyzer




Figure 8: Principle of remote configuration via radio

is described in detail in the „WACO RFAN 3.x – Software description and configuration” manual, where there are also described in details the steps how to find out current setting of a particular parameter and how to change the setting.

Purpose and importance of all configuration parameters is described in the next part of the document. Overview of all parameters that can be configured via radio can be found in the section 3.6 „Setting of module parameters via radio”. General principles and technique of radio configuration are described in details in section 3.2.3 „General rules of configuration via radio”.

3.2.2 Connection of WACO communication GateWay to computer

WACO Communication Gateway is the device intended for communication among a WACO supported software application (e.g. RFAN 3.x) and all subordinate elements of WACO wireless network. The GateWay can be connected to the computer with the RFAN 3.x application directly (through a convenient port of PC) or indirectly through the IP network. „WACO USB GateWay” (with USB support) as well as „WACO Ethernet GateWay” (with ethernet support) can be connected directly, while „WACO Ethernet GateWay”, and „WACO GSM GateWay” can be connected indirectly, what means that the GateWay is not connected to the computer with analyzer, but it is connected to the remote Ethernet/IP port of the IP-network (Internet) anywhere over the world provided that there is an IP-connection between the computer and the GateWay (see figure 8).

Connect WM868-RFU (WACO USB GateWay) to the USB port of computer with RFAN 3.x program. The module is powered from the USB port of computer, so it automatically goes „on” and three virtual serial ports are activated: one for data connection, one for configuration and one for possible firmware upgrade. The device appears in the „Other devices” section of the „Device manager” window and its virtual serial ports appear in the „Ports (COM and LPT)” section as depicted in the figure 9.




Figure 9: Appearance of WACO USB GateWay in the MS Windows „Device Manager”

If there is no appropriate driver with support of multiple virtual serial ports over USB installed in the computer, it is not possible to select serial port in RFAN 3.x setting (no serial port is available for choice). In this case the virtual serial ports appear in the „Other devices” section of „Device Manager” and it is necessary to install appropriate driver according to the instructions stated in part 3.4 „USB GateWay and USB-IRDA driver installation”.

3.2.3 General rules for configuration via radio

RFAN 3.x Analyzer enables remote configuration of WACO radio devices. This function is accessible in folder „Remote Config”. The principles of the configuration tools are following:

- select the device to be configured (or read current configuration)

- select variable that should be changed (or read)
- launch function „GET” for reading current value, or „SET” for changing of value or „WALK” for reading of all values

When performing of configuration (i. e. making changes or just reading of current settings) keep these general rules:

1. the configuration cannot be made in bulk, there must be always only one device chosen that will be configured;
2. each single variable is set up/queried by a single command/query;
3. there is a possibility to define more configured/queried variables within the tool and run their configuration/query by one click as a sequence, nevertheless, the configuration/querying of each variable is processed individually, one after another, in the order in which the sequence was set up;
4. in case the „WALK” command for querying the current status of all module’s variables is used, the analyzer starts dispatching queries that will ask the individual variables step by step;
5. when a „SET” command was sent to device, the device will proceed the command (or not – see rule 6. and 7.) and turns back a value that is really valid after the command execution;
6. if a „SET” command was sent to a variable, that is of „Read Only” character (for example type of the device, or serial number), then the device will not process the command and turns back current value of the variable;
7. if a „SET” command contains such value that is out of the defined range of values of the variable, or that has no sense, then the device either not process the command or change the variable to closest possible value. In any case, the device will send back the value which is really set after proceeding the command;
8. if a „GET”/„SET” command contains variable that is not implemented in the particular device (the device „doesn’t recognize” the variable), then the device turns back „null” value which appears in the analyzer as not accomplished command/query.

3.2.4 Remote configuration with using of RFAN 3.x Analyzer in steps

The configuration could be performed in „Remote configuration” mode (fold „Remote Config”). Add the device that should be configured into the left section of the screen by using of „Add RF Address” option of the section context menu (displayed by right-click). The new „Add RF Address” window (form) will open, where there it is necessary to fill in:

- fill device RF address in hexadecimal format marked „0x” (for example „0xffff6d”)
- tick the „Wake On Radio” option for battery powered modules
- write any description into the „Description” field for better module recognition
- by clicking to „Add” button add the device into the configuration list.

Entering of a device into the „RF Address” window is depicted in the left part of the figure 10.




Figure 10: Entering of devices and variables into the remote configuration window

Create the sequence of variables that should be configured (query or set) by clicking on „Add Variable” option in the right section context menu. The new „Add Variable” window (form) will open, where there it is necessary to edit following fields:

- into OID field (Object ID) select a name of variable that should be added in the sequence

- in case the variable has an index, put the index number in (information box „Has Index“ is ticked and „Index“ box is editable);
- set up required value of the variable into the „Value“ field. If the variable will be just read (checked its current value), leave the field blank. Those variables, that have „Read only“ status (invariable constants, measured values) will have the „Value“ box uneditable;
- by clicking on „Add“ button add a variable to the sequence of variables used for configuration.

Entering of a variable into the „Variables” window is depicted in the right part of the figure 10.

Command **GET** (reading the current variable value), **SET** (setting up the required variable value), or **WALK** (reading the current status of all variables) will be done only for one chosen device from the list of devices in „**RF Address**“ tab. Run the required command by clicking on relevant button in the top of the screen. After the click, there will appear an information window in which a progress of getting/setting process of will be displayed. As the individual settings are performed, the „tick” symbols in the „Done” box appear item-by-item. The „Getting/Setting” window will disappear after the all commands of the sequence are being accomplished, or after the expiration of the preset time limit (TimeOut). The current variable values are listed in the field „Value” in the relevant row.



Figure 11: Progress of getting values of preselected variables of the module by using of „GET” command

To avoid serious mistakes that can bring the module into paralyzed condition, numb for further communication, it is necessary to know the meaning of all modified variables of the device, including their mutual relations.

Example: If value of „SLRF Test Flag” variable is set to „1”, the module will be preset to send test messages in period which is set up by variable „SLRF Test Timeout [ms]”. In this case the period is just 1 millisecond. The trouble will occur if the test broadcasting would be switch on. It is necessary to set some reasonable period (e.g. 5 second) first and just then switch test broadcasting „on”, otherwise the module would broadcast permanently and never be able to receive any other command.

When configuring battery powered modules, always use the „Wake-On-Radio” (WOR) function. The function enables to „wake up” the module with a special „waking” radio signal from „hibernation” mode (that means the mode in which the module is almost permanently) to the mode of active signal reception. Keep in mind that by „waking up” of the particular required module the other modules, that are placed within the GateWay current radio range, will also be activated. Excessive activating of the module can cause the reduction of its battery life. To avoid the excessive „waking” of many modules around the GateWay it is recommended to follow these instructions:

- do not change the parameters if it is not necessary for the module’s functionality; - consider the succession of the configuration commands (or prepare them as a „template”); - do not use command „WALK” if not necessary - (reading of all module variables); - find suitable place for the configuration, that is in a good reach of configured device.

We also recommend keeping the modules in closed boxes, shielded with aluminum foil (or in metal boxes) so the modules are protected from the excessive „waking up” and their batteries won’t be damaged. When you do the preliminary configuration before mounting, always take out from the shielded box only the necessary number of modules. After their configuration, the modules should be placed back in the shielded box.

3.3 USB-CMOS converter driver installation

If the computer operation system failed in automatic installing of the driver for the „USB-CMOS”, it is necessary to install the driver manually. The relevant current driver can be found on a chip manufacturer’s (FTDI) webpages, namely in the „VCP Drivers“ (Virtual COM Ports) section.

www.ftdichip.com/Drivers/VCP.htm

In the „Currently Supported VCP Drivers” table find a link to a driver relevant to your operating system. To download the file, click on a link in the table. After downloading the file (in .ZIP format) into any directory in

your computer, unzip the file. It will create a new folder (directory) with a set of files (e.g. „CDM 2.08.24 WHQL Certified”).

Connect the converter „USB-CMOS“ to your computer and open a „Device Manager” tool. The converter with the disabled driver will be displayed in the top right corner of the window as „Other Devices” (see figure 13 left).




Figure 12: Appearance of converter without driver in the Windows „Device Manager” table

Click by right mouse button on „USB Serial Port” and choose „Update Driver Software” option in the context menu. Choose „Find Driver in this computer” option in the „Update Driver Software” window. Use „Browse” button to set up the path to the driver’s folder (directory) and then click on the „Next” button. The driver installation process will launch. After the driver installation is completed, the standard „Installation Completed” message will appear. After the installation the converter will appear in the „Ports (COM and LPT)” section of the „Device Manager” window (see figure 13 right).

3.4 „USB Gateway” and „USB-IRDA” driver installation

The driver „ugw3.inf” intended for support of multiple virtual serial ports through the USB interface of a computer is a part of delivered installation pack. If your version of MS Windows operating system failed in automatic installation of a driver for connected „USB Gateway” or „USB-IRDA” device, make an installation of „ugw3.inf” driver manually.

Connect the device to computer and open a window of „Device Manager” tool. The device appears in the „Other device” section in upper part of the window as „USB Serial port” device (see figure 13 left).




Figure 13: Displaying of the device without driver in ”Device Manager” window

By right-clicking to „USB Serial port” open the context menu and choose „Update driver software” item. Click on „Find driver in this computer” in the opened window. Click to „Select driver from the list” and „Next” in next window. After a new „Select device type from the following list” window appears, select „Ports (CPM & LPT)” in the window and click to „Next” button (see figure 14 left). Choose „From disc” in the next „Choose driver which you want to install” window (figure 14 right).

After that a new „Find file” window appears. Set the folder with driver file in the „Browse” tool, select „ugw3.inf” file name that will appear in the window and click to „Open” button (see figure 15 left). A new „Choose driver to be installed for the hardware” window will appear, select „RFU Gateway Serial port” item and click to „Next” button (see figure 15 right).




Figure 14: Manual selection of the driver file from a folder




Figure 15: USB driver installation

A new „Driver software installation” window will appear with standard red „unknown driver producer” Windows system warning. Click to „Install the software anyway” option and the installation process will launch (*). After the process is completed the system shows positive message „The driver was successfully installed” (or similar). The device will move to the „Ports (COM & LPT)” section of the „Device Manager” window (see figure 13 right).
 (*) If installing the driver into the Windows 8 or Windows 10 OS computer, it could be a security problem with the installation because the driver doesn't have a digital signature („unsigned driver“). In this case follow the instructions below.

3.4.1 How to disable driver signature enforcement in Windows 8 system

Enforcement of signed driver installation in Windows 8 can be disabled by following procedure:

- by pressing the „Windows + R” keys open the „Run” window;
- write a restart command ”shutdown.exe /r /o /f /t 00” into the „Open” editable field;
- choose „Troubleshoot” option in the „Choose an option” window that will pop-up;
- choose „Advanced options” in opened „Troubleshoot” window;
- choose „Windows Startup Settings” in opened „Advanced options” window and run „Restart”;
- during the system restart process a window „Advanced Boot Options” appears, choose „Disable Driver Signature Enforcement” option in this window;
- after launching the system install the driver according the above mentioned instructions.

Deactivation of the enforcement of signed driver function of the Windows 8 operating system is functional only until the next restart of the system.

3.4.2 How to disable driver signature enforcement in Windows 10 system

Enforcement of signed driver installation in Windows 10 can be switched-off by following procedure:

- click to „Windows” icon in left the bottom left corner of the screen and choose „Settings” icon;
- select „Update and security” in „Settings” window;
- select „Recovery” in next window’;
- select „Advanced startup” section in „Recovery” window and click to „Restart” button in the section;
- in a few seconds the new „Choose an option” screen appears; select „Troubleshoot” option;
- in next steps select „Advanced options” and „Startup repair” options and click to „Restart” button;
- in this step an instruction for entering of „BitLocker” recovery key could appear (depends on the system settings). This is a 64-character access key for data section of the user that can be used in case of loss of OS Windows password. The key can be found in the „Microsoft Account Settings” page, that can be displayed by clicking to „Windows” icon and „User” item of main Windows menu. To get to the account it is necessary to click to „Change account setting” and „Manage my Microsoft account” and log into the account by using of Microsoft user login/password. Select „Device” in main menu of the user account page and click to „Obtain BitLocker recovery key” in „Desktop” section and „Bitlocker” subsection. The new screen with recovery keys will open. Copy down the key that is valid for the required unit (according to the required unit identifier);
- after entering of the key the new screen with startup options will appear, select „Disable Driver Signature Enforcement” option from the list. The selection can be done with using of F1 - F10 keys, for selected option with order number „7” press key „F7”;
- after OS Windows restart perform the driver installation according to the above described procedure.

Deactivation of the enforcement of signed driver function of the Windows 10 operating system is functional only until the next restart of the system.

3.4.3 Support of older OS Windows versions and OS Linux support

Earlier MS Windows versions (Vista, Windows XP and older ones) do not support sufficiently the installation of multiple virtual serial ports onto one physical USB port and the current versions of „USB GateWay” and „USB-IRDA” devices cannot be connected to the computers with these operating systems.

There is no need to install any drivers with serial port support to the computer with Linux OS as the Linux system will automatically use its own generic drivers.

3.5 Setting of WM868-SI4-LP-H module parameters by configuration cable

In following part of the document there is a description of these parameters of the WM868-SI4-LP-H module, that can be displayed and examined from PC connected to the module by configuration cable. Some of the parameters can be changed by configuration commands entered „from the console” as described in paragraph 3.1.

3.5.1 List of WM868-SI4-LP-H module configuration parameters and commands

List of all configuration parameters of the module can be displayed by entering of ”/“ command and pressing of „ENTER” key.

The following list of parameters will display in the terminal window:

```
si4h>/
CONFIGURATION: OK
RF Address: 0xFFFEF41
hop count: 3
group: 23
SLRF flags:
test timeout: 1
channel: 1
TX Power: 5
RF Driver flags: CW
RX timeout: 4
SISA master: 0x010000FE
Sending time: 1800
Repeat: 1
Repeat timeout: 1
ADC sampling: 300
i[0]  0 0 1 1 0
i[1]  0 0 1 1 0
i[2]  0 0 1 1 0
i[3]  0 0 1 1 0
Crypt Keys for:
Run test: 0
Debug level: 0
si4h>
```

Overview of configuration parameters with short description of their meaning can be also found in table 2 on the page 26.

List of all configuration commands ("HELP") can be displayed by entering of "/"? command into the command line and pressing of „ENTER” key. The following list of commands will display in the terminal window:

```
si4h>/?
/W - write configuration
/# - erase configuration
/x - RESET
/@@@ RF address - (in hexadecimal)
/h number - hop count (0-15)
/g number - group address (0-65535)
/f[+-] flags - e-extender, Z-AZRA algorithm
/T number - test timeout (in 1/20 sec.)
/c number - channel
/P number - TX power in dBm
/F[+-] flags - C-CD detect, R-RX only, W-WOR active, G-high gain
/X time - RX timeout (50ms)
/!!! (f freq_in_khz | freq_const)
/m RF_address - master address
/s number - sending time in sec.
/R number - # of attempts to deliver data
/A number - repeat timeout in 50 ms steps
/a number - sampling timeout in sec.
/i index value - set initial value
  index t number- set type
  index e 0|1 - set edge
  index m value - set multiplier
  index d value - set divisor

/K port d - delete key
port key- add/change key

/E number - run test
/w - send empty WOR packet
/D number - debug level
si4h>
```

The meaning of individual parameters and detailed description of their usage can be found in the following part of chapter 3.5.

3.5.2 „Configuration” group of commands for writing of configuration and reset

The module contains two sets of configuration: operating configuration and saved configuration. At the start of the system the module copies saved configuration into the operating configuration, with which continues to work. If the user changes configuration parameters, it does so only in operating configuration.

Current status of storing of configuration parameters can be displayed in the list of all configuration parameters as „CONFIGURATION” item:

```
CONFIGURATION: OK
```

Information „OK” means, that the operating configuration is stored (it is identical with stored configuration)

Information „NOT WRITTEN” means, that the operating configuration is different from the configuration stored in Flash.

Configuration **can be saved** to Flash memory by using of ”/W” command. Example:

```
si4h>/W
```

If the current operating configuration was not stored to FLASH memory, the module returns to the saved configuration after reset. If the parameter should be changed only temporarily (for example switch-on „test” function during diagnostics), it is not necessary to save operating configuration into FLASH memory (after diagnostics the

function will be switched-off anyway). If the parameter should be changed permanently, there is necessary to save the configuration to FLASH memory.

Configuration can be **erased from the Flash memory** by using of `"/#"` command. Example:

```
si4h>#
```

WARNING! This command is recommended to use only by users with good knowledge of the system, or after consultation with the manufacturer.

The **module reset** can be performed by using of `"/x"` command. Example:

```
si4h>/x
```

After entering the command the module goes to software restart.

Change of some configuration parameters has an effect only after module reset (e.g. retuning of module radio by changing of „SLRF Channel” parameter). In this case it is recommended to create a configuration sequence containing commands for change of parameter, saving the change to Flash, as well as command for performing of module reset (..and exactly in this order).

3.5.3 Commands for settings of radio-frequency subsystem

This group of commands enables setting of transmitting, receiving, repeating and addressing system. There are following commands:

<code>/c number</code>	<i>frequency channel setting (SLRF Channel)</i>
<code>/h count</code>	<i>maximum number of re-transmissions (SLRF Hop Count)</i>
<code>/f[+-] flags</code>	<i>repeating mode setting (SLRF flags)</i>
<code>/F[+-] flags</code>	<i>transceiver mode setting (RF Driver flags)</i>
<code>/g group</code>	<i>setting of group address (SLRF Group Address)</i>

Names of parameters that are configured by individual commands are stated in the brackets.

The **„SLRF Channel”** parameter is a number of module frequency channel. RF modules of WACO communication system can be tuned to any of three separate frequency channels that don't influence each other.

Frequency channel of the module can be set by `"/c [number]"` command, where value 0, 1, or 2 means number of frequency channel to be tuned. Change of frequency channel is effective only after module reset. Example of sequence of commands for module setting to the frequency channel "1":

```
si4h>/c 1
si4h>/W
si4h>/x
```

The **„SLRF Hop Count”** parameter is a maximum number of re-transmissions of the messages, broadcasted by the module. If, as an example, the parameter is set to value "3", each message originated by the module will be discarded after three re-transmissions (it is repeated no more than 3 times). This mechanism prevents the system from uncontrolled circulation of the message within the network. It is recommended to set the parameter to "n" or n+1" value, where "n" is the least number of re-transmissions which is necessary to get the message to its destination. If the „SLRF Hop Count" value is too low, the message is discarded before reaching of its destination. If the „SLRF Hop Count" value is too high, capacity of the network is loaded by useless repeating of the messages.

The „SLRF Hop Count" parameter can be set by `"/h [number]"` command, where the value from 0 - 15 interval means the maximum number of re-transmissions ("hops") of the messages, broadcasted by the module. Example of command for setting of „SLRF Hop Count" parameter to value of 3 "hops":

```
si4h>/h 3
```

The **„SLRF Repeater flags”** parameter is intended for setting of repeating (re-transmission) mode. Repeating mode can be set by using of `"/f[+-] [flags]"` command, where the required mode is chosen by entering of one of following pre-defined symbols („flags”):

- value " " (without flag) - none of below mentioned functions is involved

- value "e" - setting of basic repeating mode (without back transfer suppression)
- value "Z" - setting of advanced repeating mode with back transfer suppression (AZRA)

During normal operation the WM868-SI4-LP-H module stays mostly in „hibernated” state and it is switched to active receiving/transmitting state only for the very short time interval, when the message is transmitted. For that reason the possibility of repeating messages from other modules is so limited, that it is practically unusable. It is recommended to leave the parameter in default setting (SLRF flags: " ") with repeating function switched off.

The „**RF Driver flags**” parameter is intended for setting of module transceiver mode. The mode can be set by using of "/F[+-] [flags]" command, where the required transceiver mode is chosen by entering of one or more of following pre-defined symbols („flags”):

- value "C" - full anti-collision protection (carrier and frame transmission detect) enabled
- value "R" - limited anti-collision protection (carrier detect) enabled
- value "W" - „Wake On Radio” (WOR) function of the receiver enabled
- value "G" - „High Gain” function enabled (it has no effect for WM868-SI4-LP-H module)

Important note:

The "C" and "R" functions are alternative options and their setting works as a **change-over switch** (when one of them is enabled, second one is automatically switched off). The "W" and "G" functions are independent. Their flags can be added or removed **individually** by using of +/- symbol before the flag.

Example of command for common setting of „Full anti-collision protection” and „Wake On Radio” functions and corresponding record in the module configuration summary:

```
RF Driver flags: R
si4h>/F C +W
RF Driver flags: CW
```

Example of command for switching of protection to „Limited anti-collision protection” mode and corresponding record in the module configuration summary:

```
RF Driver flags: CW
si4h>/F R
RF Driver flags: RW
```

As seen in the example, by enabling of "R" function the original "C" function was automatically switched off and it had no influence on the "W" function.

Example of disabling of "W" function and corresponding record in the module configuration summary:

```
RF Driver flags: RW
si4h>/F -W
RF Driver flags: R
```

As seen in the example, disabling of "W" function had no influence on the "R" function.

Example of command for common setting of "W" and "G" functions and corresponding record in the module configuration summary:

```
RF Driver flags: R
si4h>/F +W +G
RF Driver flags: RWG
```

Example of command for switching of anti-collision protection to "C" mode together with disabling of "G" function and corresponding record in the module configuration summary:

```
RF Driver flags: RWG
si4h>/F C -G
RF Driver flags: CW
```

*When the „**Full anti-collision protection**” function is switched on, the module opens its receiver for an instant before broadcasting and „listens” whether the frequency channel is clear. If a carrier frequency is detected or transmission of a frame is underway, the module postpones broadcasting of the message for a moment and then tries again. This procedure protects transmission of the message from interference with disturbing signal on the same frequency as well as from collision with broadcasting of other modules.*

When the „**Limited anti-collision protection**” function is switched on, the module goes to transmission if there is no other frame underway (but, unlike the full protection, detection of carrier is not performed). This procedure does not protect broadcasting against disturbing signal, but protects transmission of the message from collision with broadcasting of other modules. This setting is recommended in this case when the module works in the environment with permanent disturbance of carrier frequency and it has no sense to waste time (and battery power) by waiting for clear channel.

Important note! Even the functions of anti-collision protection are identical for all modifications of the WM868-SI4-LP-H module, older version of the module can have **adifferent way of switching between full and limited protection**:

- for switching to full anti-collision protection use flag ”C” - for switching to limited anti-collision protection use „empty flag” (” ”).

Switching from factory preset full anti-collision protection mode (”RF Driver flags: C”) to the limited anti-collision protection mode can be performed this way:

```
RF Driver flags: C
si4h>/F
RF Driver flags:
```

By using of ”/F” command without flag all current flags will be removed. After that required flag (e.g. ”W”) can be added by ”/F +W” command.

When the „**Wake On Radio**” (WOR) function is enabled, the module can be anytime remotely activated from hibernated state with using of a special „wake-up” radio signal. This function is quite essential for the module, because it enables reading of data on demand (in „walk-by” mode) as well as performing of remote diagnostics and configuration via radio as described in the section 3.6.

The „**SLRF Group Address**” parameter can be used for setting of module group address. Practically unlimited number (65536) of groups can be created within each WACO RF network and these addresses can be also used for addressing (besides individual addresses). If a group address is used, the message is delivered to all modules of that group. As the WM868-SI4-LP-H module’s current applications use „broadcast” type of addressing, setting of group address is not required. But it is possible, that some of the applications could use group addressing in future.

Setting of **module group address** („SLRF Group Address”) can be performed by using of ”/g [number]” command, where the number from 0 - 65535 interval is the module group address. Example of setting of the group address to the ”21” value and corresponding record in the module configuration summary:

```
si4h>/g 21
...
group: 21
```

3.5.4 Time constants and number of repetitions

This group of commands enables setting of measurement and transceiver time constants and setting a number of the message repetitions. There are following commands:

/X time	receiving time interval (50 ms)
/s number	spontaneous messages broadcasting period (sec)
/R number	maximum number of repetitions of unconfirmed message
/A number	time interval between message repetitions (50 ms)
/a number	A/D converter measurement interval (sec)

The „/X time” command is intended for setting of „receiving time interval”, what is the interval immediately after sending a message in which the module’s receiver is active. This interval enables unbroken wireless communication with the module in case of using of Wake-on-Radio (WOR) system. As the module does not switch to hibernation immediately after transmitting of data, it is possible to send another query subsequently. The interval is set in „system units” of 50 ms (20 units = 1 second). Example of setting of receiving time interval parameter to 200 ms (4 units) value:

```
si4h>/X 4
```

WARNING! When using Wake On Radio (WOR) system in the module operation, it is necessary to set the /X parameter to **at least 150 ms (3 units) value**. Recommended value for reliable working of WOR system is 200 ms (4 units).

The „/a number” command can be used for setting of the time interval for Analog-to-Digital (A/D) converter measurement. The module is equipped with A/D converters for measurement of some operational parameters (e.g. temperature, voltage...) and the measurement is performed in the preset intervals (set in seconds). As the latest values of measured quantity are broadcasted in INFO-messages, measurement interval should be always significantly shorter than broadcasting period. Example of setting of A/D converter measurement interval to 5 minutes (300 seconds) value:

```
si4h>/a 300
```

The „/s number” command can be used for setting of the module **broadcasting period**. The period is set in seconds and the module broadcasts its INFO-messages spontaneously with this period. Example of setting of broadcasting period to 1 hour (3600 seconds):

```
si4h>/s 3600
```

Following two commands are intended for setting of **repetitions of unconfirmed message**. The module supports also the applications that require confirmation of delivered message by its addressee. If the sender does not receive a confirmation message („acknowledgement”), repeats the message again after some time interval. If the module does not use any application with confirmation of the messages, setting of following parameters has no practical meaning and it is recommended to leave them in the factory setting.

The „/R number” command can be used for setting of maximum number of message repetitions if the delivery is not confirmed. Factory setting is ”1” (without repetition). Example of setting of maximum number of message repetitions to 1 value:

```
si4h>/R 1
```

The „/A number” command can be used for setting of the time interval between repetitions of unconfirmed message. The interval is set in „system units” of 50 ms (20 units = 1 second), factory setting is 50 ms (1 unit). Example of setting of the time interval between repetitions to 50 ms (1 unit) value:

```
si4h>/A 1
```

As the main application of the WM868-SI4-LP-H module („SISA-TX”) does not support confirming of messages, setting of message repetitions has no practical meaning.

3.5.5 Commands for setting of input counters

The WM868-SI4-LP-H module is equipped with four input pulse counters (index 0 - 3) and enables reading of up to four consumption meters with pulse output or sensors. As each input counter can be set individually, different types of devices (meters or sensors) can be connected (with different kind, initial status, multiplier or divisor).

Setting of pulse inputs can be performed with using of following commands:

/i index value	setting of initial value of the counter
/i index t number	setting of counter mode: 0-quick pulses, 1-edges, 2-slow pulses
/i index e 0/1	setting of trigger edge (not used)
/i index m value	setting of multiplier (not used)
/i index d value	setting of divisor (not used)

By using of the „/i index value” command setting of the **initial values** of individual input counters can be performed. Initial value of the input should be entered as a natural number.

Example of setting of the second input counter to the initial value „24”:

```
si4h>/i1 24
```

By using of the „/i index t number” command an **operation mode** of the individual input counter can be chosen. Standard („quick”) mode can be preset by value ”0”, „slow” mode with equalizing filter can be preset by

value "2". Value "1" is reserved for switching to the „edge detection" mode, that is not implemented in the current modification of the WM868-SI4-LP-H module.

Example of command for setting of the first input counter to the „slow" mode:

```
si4h>/i0 t2
```

The „/i index e 0/1" command is intended for closer specification of the „edge detection" mode. As this setting has no practical meaning for the WM868-SI4-LP-H module, it is recommended not to use this command.

The „/i index m value" and „/i index d value" commands are reserved for setting of multiplier and divisor constants for adjusting of output values to required output units. As the constants are not applied in the current modification of the WM868-SI4-LP-H module, setting of these parameters has no practical effect.

Overview of current setting of all parameters of all input counters can be performed with using of „/i" command:

```
si4h>>/i
i[0]  0 0 1 1 50
i[1]  2 0 1 1 24
i[2]  0 0 1 1 126
i[3]  2 0 1 1 18
si4h>
```

Parameters of each input counter are displayed in one row of the statement in following order: mode - edge - multiplier - divisor - current value.

3.5.6 Setting of test broadcasting

These commands can be used for setting of **test broadcasting function** of the module, that can be used for evaluation of radio signal in the installation site. When this function is switched on, the module broadcasts test messages in regular intervals and a quality of their reception can be evaluated around the module with using of WACO RF analyzer or any similar device.

The „/T" command can be used for setting of **period of the test broadcasting**. Length of the period is entered in „system units", where the value of one system unit is 50 ms (value of „100 units" means 5 second period). Example of setting of the testing period to 10 second (200 system units):

```
si4h>/T 200
```

By using of the „/E [0/1]" command the function of **test broadcasting can be switched "on" and "off"**. Test broadcasting is switched on with using of „/E 1" command, and it is disabled by using of „/E 0" command. Example of test broadcasting switching "on" command:

```
si4h>/E 1
```

WARNING! Do not set "T" parameter to less than "50" value, otherwise the module buffers could be overloaded.

3.5.7 Special commands for module activation and diagnostics

This group of commands is intended for the module initial setting during the manufacturing process, and for module diagnostics by manufacturer. It is strongly recommended using of these commands only by users with a very good knowledge of the system, or only after consulting with manufacturer. There are following commands:

/@@@ RF address	<i>insertion of module RF address (it can be done only once, not editable)</i>
/K port key	<i>insertion of AS128 encryption key for the particular application („port")*</i>
/K port d	<i>removal of AS128 encryption key for the particular application („port")*</i>
/P number	<i>transmitting power setting (Do not use! Only for factory setting!)</i>
/!!! f num.	<i>correction constant setting (Do not use! Only for factory setting!)</i>
/w	<i>send empty WOR packet (Do not use! Only for factory setting!)</i>
/D number	<i>„debug" statement switch-on (Do not use! Only for factory setting!)</i>

* none of the WM868-SI4-LP-H module applications currently use the data encryption with AS128 key

3.5.8 Module current status statement

The **module current status statement** can be displayed by entering of "i" command (without „slash") into the command line and pressing of „ENTER" key. Following statement will appear in the terminal window:

```
si4h>i
SI4H HW 1.70 SW: 5.0
0:43:33 1.1.1900 Reset cause=4 Uptime=2614
temperature[1]: -500.0
temperature[2]: +31.1
voltage[1]: 3336
rtc: 2613
si4h>
```

In the first row there are displayed following device specifications: **manufacturer type** (Device name), **hardware version/revision** (HW version.revision) and **software version/revision** (SW vesion.revision).

In the second row there are values of module **system time** in common time format, **reset cause** of module last reset and value of module "Uptime".

In next rows there are values of **current temperature** measured by sensor (Temperature [1]), **current processor temperature** (Temperature [2]) and **current voltage of internal battery** (Voltage [1]). As the module is not equipped by temperature sensor, the "Temperature [1]" value is a random number with no practical meaning. In the last row there is a value of module system time in seconds after midnight ("rtc").

The „**Systime**" parameter value shows setting of module real time. System time is kept in the same format as in computer operating systems, i.e. in seconds, starting from 1.1.1970 („UNIX Epoch time"). In default status (after battery switch-on) there is zero value in the counter and it increases by one every second. The module can be synchronized with the real time only via radio, by using of the "**SET**" command of the WACO RFAN analyzer (see paragraph 3.6.2). Setting of this parameter is not required for any common application of the module.

The „**Uptime**" parameter value shows the time interval passed from the last device reset in seconds so that the exact moment of the last module reset can be recognized by this parameter. The parameter cannot be changed by user („read only" type).

The „**Reset Code**" parameter value gives an information about the last reset circumstances. Following reset codes are relevant for this type of device:

- „0" means „Cold start" (caused by user „RESET" command)
- „1" means „Warm start" (based on „suspension" cause)
- „2" means „Watchdog reset" (reset by „watchdog" system)
- „3" means „Error reset" (incorrect instruction or inconsistent data)
- „4" means „Power reset" (caused by low power voltage)

The parameter has „read only" character and it is used mainly for the diagnostics.

3.6 Setting of WM868-SI4-LP-H module parameters via radio

In following part of the document there is a description of these parameters of the WM868-SI4-LP-H module, that can be checked via radio (by using of GET or WALK command) as described in the chapter 3.2 „Configuration of the module via radio". Some of the parameters can be also changed via radio by using of "SET" command.

3.6.1 Module description and identification parameters

The first group of variables of the WM868-SI4-LP-H module serves for the device identification and description. These variables are load up into the module configuration by the manufacturer and are „Read Only". There are following variables:

OID	Index	OID Name	Description	Example
1	N/A	Device name	device name by manufacturer	T40
2	N/A	Device type	device type by manufacturer	868
3	N/A	Device subtype	device subtype by manufacturer	101
4	N/A	Manufacturer #	device RF address	0xff 0xff 0xea 0xb5
5	N/A	HW Version	hardware version by manufacturer	1
6	N/A	HW Revision	hardware revision by manufacturer	5
7	N/A	SW Version	software version by manufacturer	4
8	N/A	SW Revision	software revision by manufacturer	2

As it is evident from the table, these variables enable identification of the module by individual RF address and provide an additional information about its production series, software version etc.

Variables „Device Name” and „Manufacturer #” are very important for the device identification in case of re-configuration, repair or service maintenance. The rest of the variables are relevant mainly to the manufacturer for monitoring and evaluating the system operation and the malfunction diagnostics.

3.6.2 Setting of the module System Time

The „Systemtime” variable serves for setting of module real time. This parameter can be configured only via radio, but its setting is not required for any common application of the module. System time is kept in the same format as in computer operating systems, i.e. in seconds, starting from 1.1.1970 („UNIX Epoch time”). The module can be synchronized with the real time by the ”SET” command of the WACO RFAN analyzer, where the ”Systemtime (s)” variable is selected in the ”OID” field and an actual time in the ”UNIX time” format is entered into the ”Value” field of the ”Add variable” form (see figure 16).




Figure 16: Setting of module System Time via radio

3.6.3 Uptime, configuration status and reset cause parameters

This group of variables is used mainly as an additional information about the device status within its diagnostics. There are following variables:

OID	Index	OID Name	Description	Example
12	N/A	Uptime (s)	working time from the last reset in seconds	335962
14	N/A	Reset code	recent reset type (reason)	0
15	N/A	Configuration status	storing of configuration parameters	2

The „Uptime” variable shows the time interval passed from the last device reset in seconds. The exact moment of the last module reset can be recognized by this parameter and together with the „Reset Code” parameter (see below) it is also possible to recognize the cause of the reset. The parameter cannot be changed by user („read only” type).

The „Reset Code” variable gives an information about the last reset circumstances. Following reset codes are relevant for this type of device:

- „0” means „Cold start” (caused by user „RESET” command)
- „1” means „Warm start” (based on „suspension” cause)
- „2” means „Watchdog reset” (reset by „watchdog” system)
- „3” means „Error reset” (incorrect instruction or inconsistent data)
- „4” means „Power reset” (caused by low power voltage)

Reset code is used mainly for the diagnostics purposes. Setting of this variable to any value except „0” by SET command will cause an immediate **reset of the module**.

The „**Configuration status**” variable gives an information about the storing of configuration parameters into the device’s FLASH memory. The variable can have following values: - „**0**” - empty (erased) FLASH, operating configuration is loaded by default values

- „**1**” - configuration not saved in FLASH (FLASH content is different than operating configuration)
- „**2**” - configuration saved in FLASH (FLASH content is same as operating configuration)

Setting of this variable to „**2**” value by SET command will cause immediate **saving of current operating configuration** into FLASH memory.

The module contains two sets of configurations: operating configuration and saved configuration. At the start of the system the module copies saved configuration into the operating configuration, with which continues to work. If the user changes configuration parameters, it does so only in operating configuration.

If the current operating configuration was not stored to FLASH memory, the module returns to the saved configuration after reset. If the parameter should be changed only temporarily (for example switch-on „test” function during diagnostics), it is not necessary to save operating configuration into FLASH memory (after diagnostics the function will be switched-off anyway). If the parameter should be changed permanently, there is necessary to save the configuration to FLASH memory. Change of some configuration parameters has an effect only after module reset (e.g. retuning of module radio by changing of „SLRF Channel” parameter). In this case it is recommended to create a configuration sequence containing commands for change of parameter, saving the change to Flash, as well as command for performing of module reset (.and exactly in this order).

3.6.4 Parameters „Input value”, „Temperature” and „Voltage”

This group of variables can be used for displaying of user data measured by the module. Current status of these variables is regularly broadcasted in the module „INFO” messages. There are following variables:

OID	Index	OID Name	Description	Example
100	1	Input value	Current status of counter 1	0
100	2	Input value	Current status of counter 2	0
100	3	Input value	Current status of counter 3	0
100	4	Input value	Current status of counter 4	0
105	2	Temperature	Processor temperature in tenths of Celsius	203
106	1	Voltage (mV)	Battery voltage in mV	3765

Values of „**Input value**” variable (index 1 - 4) show the current statuses of module internal counters. The values can be set to required value by using of SET command. By using of the „Input value type” (OID=98) variable each input can be set to required mode as described in the paragraph ?? „Commands for setting of input counters”.

IMPORTANT NOTE! *When setting of input counters via radio, individual inputs are identified by using of 1, 2, 3 and 4 indexes (in contrast of console configuration, where 0, 1, 2 and 3 indexes should be used).*

Value of „**Temperature**” variable with **index 2** shows the current value of module processor temperature in tenths of Celsius (value „206” means temperature of 20,6 °C). This variable is of „**read only**” type.

Value of „**Voltage**” variable shows the current value of module battery voltage in mV (value „3765” means battery voltage of 3,765 V). This parameter is important for module diagnostics, where too low value (under 3,2 V) indicates upcoming battery discharge. This variable is of „**read only**” type.

3.6.5 „SISA TimeOuts” Parameters

The „**SISA TimeOuts**” variable can be used for setting of module internal timers, that control measurement of useful data („Input value”, „Temperature”, „Voltage”) and broadcasting of the measured values in form of radio messages. The different types of timers are distinguished by different indexes of the „SISA TimeOuts” variable. The variable can use indexes with following meaning:

OID	Index	OID Name	Description	Example
109	1	SISA timeouts	spontaneous messages broadcasting period (sec)	1200
109	2	SISA timeouts	A/D converter measurement interval (sec)	60
109	3	SISA timeouts	receiving time interval (50 ms)	4
109	4	SISA timeouts	time interval between repetitions (50 ms)	3
109	5	SISA timeouts	maximum number of repetitions	1

By using of variable with **index „1”** the period of broadcasting of spontaneous INFO-messages can be configured. The INFO-message carries useful data (values of counters, physical quantities..). If, as an example, value „1200” is preset, the module automatically sends INFO message (see paragraph 1.2) every 1200 seconds (3-times per hour).

By using of variable with **index „2”** the time interval for Analog-to-Digital (A/D) converter measurement can be configured. As the latest values of measured quantity are broadcasted in INFO-messages (see paragraph 1.2), the time interval should be always significantly shorter than broadcasting period. Recommended value is in range of few minutes (value „60” means 1 minute).

By using of variable with **index „3”** the „receiving time interval” can be configured. Receiving time interval is the time interval immediately after sending a message in which the module’s receiver is active. This interval enables unbroken wireless communication with the module in case of using of Wake-on-Radio (WOR) system. The module does not switch to hibernation immediately after transmitting of data and it is not necessary to wake it up again before each query. The interval is set in „system units”, where one unit means 50 ms.

WARNING! When using Wake On Radio (WOR) system in the module operation, it is necessary to set the „receiving time interval’ parameter to **at least 150 ms** (3 units). Recommended value for reliable working of WOR system is 200 ms (4 units).

By using of variable with **index „4”** the time interval between repetitions of unconfirmed message can be configured. Some types of messages require confirmation of delivered message by its addressee. If the sender does not receive a confirmation, repeats the message again after preset interval. The interval is set in „system units”, where one unit means 50 ms. Maximum number of repetitions is set by same variable with index „5”.

By using of variable with **index „5”** the maximum number of message repetitions can be configured. If the parameter is set to „1” value, the message will be sent only once (without repetition).

There are only some applications that require confirmation of message delivery. As the main application of the WM868-SI4-LP-H module („SISA_TX”) does not support confirming of messages, setting of message repetitions has no practical meaning.

3.6.6 Radio-frequency subsystem parameters

This group of variables contains parameters of transmitting, receiving, repeating and addressing system. There are following parameters:

OID	Index	OID Name	Description	Example
110	1	SLRF Channel	frequency channel setting	0
111	1	SLRF Hop Count	maximum number of re-transmissions	3
114	1	SLRF Group Address	setting of group address	2
116	1	SLRF Repeater Flag	repeating mode setting	0
118	1	SLRF My Address	module RF address	0xff 0xff 0x1a 0xf1
122	1	SLRF CD Flag	anti-collision mode setting)	1

The „**SLRF Channel**” variable can be used for setting of module frequency channel. RF modules of WACO communication system can be tuned to any of three separate frequency channels that don’t influence each other. Value of the „SLRF Channel” variable means a number of frequency channel to which the module is tuned (0, 1, or 2). **Change of frequency channel** can be performed by setting of variable to required value by using of SET command. As the change of frequency channel is effective only after module reset, it is always necessary to send a sequence of commands for change of channel (SLRF Channel), saving of configuration (Configuration status) and module reset (Reset Code).

The „**SLRF Hop Count**” variable can be used for setting of the maximum number of re-transmissions of the messages, broadcasted by the module. If, as an example, the parameter is set to value ”3”, each message originated by the module will be discarded after three re-transmissions (it is repeated no more than 3 times). It is recommended to set the parameter to ”n” or n+1” value, where ”n” is the least number of re-transmissions which is necessary to get the message to its destination. If the „SLRF Hop Count” value is too low, the message is discarded before reaching of its destination. If the „SLRF Hop Count” value is too high, capacity of the network is loaded by useless repeating of the messages.

The „**SLRF Repeater flag**” variable can be used for setting of repeating (re-transmission) mode. Each RF module of WACO communication system can be used also for re-transmission of messages from other modules. Repeating function can be switched or disabled by setting of different values of „SLRF Repeater flag” variable, where following values can be used:

„0“ - repeating mode disabled, module does not repeat messages

- „1“ - basic repeating mode enabled (w/o back transfer suppression)
- „3“ - advanced repeating mode with back transfer suppression (AZRA) enabled

During normal operation the WM868-SI4-LP-H module stays mostly in „hibernated“ state and it is switched to active receiving/transmitting status only for the very short time interval, when the message is transmitted. For that reason the possibility of repeating messages from other modules is so limited, that it is practically unusable. It is recommended to leave the parameter in factory setting (SLRF Repeater flag = 0) with repeating function switched off.

The „**SLRF Group Address**“ variable can be used for setting of module group address. Practically unlimited number (65536) of groups can be created within each WACO RF network and these addresses can be also used for addressing (besides individual addresses). If a group address is used, the message is delivered to all modules of that group. The address can be entered as natural number from the range of 0 to 65535. The address appears in same form in the current statement obtained by command GET or WALK (see figure 17). As the WM868-SI4-LP-H module’s current applications use „broadcast“ type of addressing, setting of group address is not required.

The „**SLRF My Address**“ variable can be used for displaying of the module individual RF address. The individual RF address is unique 32-bit long number assigned to the module in factory that cannot be changed by user („read only“ variable). Each RF message originated by the module contains the module’s individual RF address in the „Source Address“ field of the message header. If a WACO RF message should be delivered to the particular module (e.g. query for its parameter), the individual RF address of addressee should be inserted to the „Destination Address“ field of the message header. The address should be entered in hexadecimal form with „0x“ sign at the beginning (e.g. „0xffffea72“). The address appears in the statement obtained by GET or WALK commands in the hexadecimal form of individual Bytes: „0xff 0xff 0xea 0x72“ (see figure 17).

Index	OID	Index	OID Name	Value	Done
1	118	1	SLRF My Address	0xff 0xff 0xea 0x72	<input checked="" type="checkbox"/>
2	114	1	SLRF Group Address	120	<input checked="" type="checkbox"/>

Figure 17: Current status of „SLRF My Address“ and „SLRF Group Address“

The „**SLRF CD flag**“ variable can be used for switching of anti-collision functions. When **full anti-collision protection** („Carrier Detect“ - CD) function is switched on, the module opens its receiver for an instant before broadcasting and „listens“ whether the frequency channel is not occupied by disturbing signal or whether the channel is not occupied by transmission of another WACO module. When **limited anti-collision protection** function is switched on, the module goes to transmission if there is no other transmission underway (but, unlike the full protection, detection of carrier is not performed). If anti-collision system (by using of one of above described methods) detects using of frequency channel, the module postpones broadcasting of the message for a moment and tries again, until the message is successfully transmitted.

This function is switched to the full anti-collision protection mode by factory setting (SLRF CD flag=1), switching to the limited protection mode (SLRF CD flag=0) is recommended when the module works in the environment with permanent disturbance of carrier frequency and it has no sense to waste time (and battery power) by waiting for clear channel.

As the WM868-SI4-LP-H module is equipped with just one radio-frequency subsystem (transceiver), all configurations of RF subsystem should be performed with using of **index 1**.

3.6.7 „SLRF Test flag“ and „SLRF Test timeout“ parameters

These commands can be used for setting of **test broadcasting function** of the module, when the module broadcasts test messages in regular intervals. This function can be used for evaluation of the module installation site (range verification), as well as for RF network maintenance, re-design or diagnostics. There are following variables:

OID	Index	OID Name	Popis	Příklad
123	1	SLRF Test flag	switching of test broadcasting function	0
124	1	SLRF Test timeout	setting of test broadcasting period (50 ms)	20

Test broadcasting can be switched ”on“ and ”off“ by using of the „**SLRF Test flag**“ variable. By setting of „SLRF Test flag“ value the function can be switched on/off as follows:

- „0“ - test broadcasting is disabled
- „1“ - test broadcasting is enabled, test messages are broadcasted with „SLRF Test timeout“ period

During normal operation the test broadcasting function is switched off (SLRF Test flag = 0, what is the factory

setting). **Before activation of this function** it is necessary to setup period of test broadcasting by **setting of „SLRF Test timeout”** variable to appropriate value (recommended range of value is 50 - 100). Too short period could cause permanent broadcasting of the module, when the module buffers are overloaded and the communicate with the device could become difficult.

The test broadcasting function should be switched off immediately after testing!

The **„SLRF Test timeout”** variable can be used for setting of the test broadcasting period when the test broadcasting function is on. Length of the period is entered in „system units”, where the value of one system unit is 50 ms, so that the value of „100 units” (example) means 5 second period.

As the WM868-SI4-LP-H module is equipped with just one radio-frequency subsystem (transceiver), setting of test broadcasting should be performed with using of **index 1**.

3.6.8 „Sequence #” parameter

The **„Sequence #”** variable is generally intended for identification (pairing) of „query-answer” sequences. None of current module applications use this function, so it has no practical use so far. It is recommended to leave the variable in default setting.

3.6.9 List of all variables displayed by ”WALK” command

List of all variables of the WM868-SI4-LP-H module that are accessible via radio, as displayed by the RFAN 3.x analyzer after using of „WALK” command, is shown in the figure 18.

Index	OID	index	OID Name	Value	Done
1	1		Device name	SI4H	<input type="checkbox"/>
2	2		Device type	868	<input type="checkbox"/>
3	3		Device subtype	104	<input type="checkbox"/>
4	4		Manufacturer #	0xff 0xfe 0xdf 0x41	<input type="checkbox"/>
5	5		HW Version	1	<input type="checkbox"/>
6	6		HW Revision	70	<input type="checkbox"/>
7	7		SW Version	5	<input type="checkbox"/>
8	8		SW Revision	0	<input type="checkbox"/>
9	12		Uptime (s)	120	<input type="checkbox"/>
10	13		System (s)	59787	<input type="checkbox"/>
11	14		Reset code	3	<input type="checkbox"/>
12	15		Configuration status	2	<input type="checkbox"/>
13	61		Sequence #	0	<input type="checkbox"/>
14	98	1	Input value type	0	<input type="checkbox"/>
15	98	2	Input value type	0	<input type="checkbox"/>
16	98	3	Input value type	0	<input type="checkbox"/>
17	98	4	Input value type	0	<input type="checkbox"/>
18	99	1	Input value level	0	<input type="checkbox"/>
19	99	2	Input value level	0	<input type="checkbox"/>
20	99	3	Input value level	0	<input type="checkbox"/>
21	99	4	Input value level	0	<input type="checkbox"/>
22	100	1	Input value	0	<input type="checkbox"/>
23	100	2	Input value	0	<input type="checkbox"/>
24	100	3	Input value	0	<input type="checkbox"/>
25	100	4	Input value	0	<input type="checkbox"/>
26	101	1	Input value multiplier	1	<input type="checkbox"/>
27	101	2	Input value multiplier	1	<input type="checkbox"/>
28	101	3	Input value multiplier	1	<input type="checkbox"/>
29	101	4	Input value multiplier	1	<input type="checkbox"/>
30	102	1	Input value divider	1	<input type="checkbox"/>
31	102	2	Input value divider	1	<input type="checkbox"/>
32	102	3	Input value divider	1	<input type="checkbox"/>
33	102	4	Input value divider	1	<input type="checkbox"/>
34	105	1	Temperature	-5000	<input type="checkbox"/>
35	105	2	Temperature	252	<input type="checkbox"/>
36	106	1	Voltage [mV]	3487	<input type="checkbox"/>
37	109	1	SISA timeouts	1800	<input type="checkbox"/>
38	109	2	SISA timeouts	300	<input type="checkbox"/>
39	109	3	SISA timeouts	4	<input type="checkbox"/>
40	109	4	SISA timeouts	1	<input type="checkbox"/>
41	109	5	SISA timeouts	1	<input type="checkbox"/>
42	110	1	SLRF Channel	2	<input type="checkbox"/>
43	111	1	SLRF Hop Count	3	<input type="checkbox"/>
44	114	1	SLRF Group Address	23	<input type="checkbox"/>
45	116	1	SLRF Repeater flag	0	<input type="checkbox"/>
46	118	1	SLRF My Address	0xff 0xfe 0xdf 0x41	<input type="checkbox"/>
47	122	1	SLRF CD flag	1	<input type="checkbox"/>
48	123	1	SLRF Test flag	0	<input type="checkbox"/>
49	124	1	SLRF Test timeout [ms]	1	<input type="checkbox"/>

Figure 18: List of all WM868-SI4-LP-H module variables displayed by RFAN 3.x analyzer

Overview of all WM868-SI4-LP-H module configuration parameters accessible via radio is shown in the Table 2 that can be found in paragraph 4.1.2. The individual items of the table are ordered by OID number same way as they display in the analyzer window after using of „WALK” command

3.6.10 Overview of module configuration parameters

Overview of configuration parameters that can be used for user settings of the WM868-SI4-LP-H module is shown in the Table 2 below. The parameters are presented in the same order as they appear in the List of configuration parameters obtained by „WALK” command of wireless configuration via radio (see paragraph 3.6.9).

Table 2: Overview of WM868-SI4-LP-H module configuration parameters

OID	Index	OID Name	Description	Default
1		Device name	Manufacturer device name	read only
2		Device type	Manufacturer device type	read only
3		Device subtype	Manufacturer device subtype	read only
4		Manufacturer #	Device serial number (RF address)	read only
5		HW Version	Device hardware version	read only
6		HW Revision	Device hardware revision	read only
7		SW Version	Device software version	read only
8		SW Revision	Device software revision	read only
12		Uptime	Device uptime from reset (s)	read only
13		Systime	System time in seconds	read only
14		Reset code	Las reset code	read only
15		Configuration status	Configuration saving status	read only
61		Sequence #	Transaction sequence number	0
98	1	Input value type	Mode of counter 1	0
98	2	Input value type	Mode of counter 2	0
98	3	Input value type	Mode of counter 3	0
98	4	Input value type	Mode of counter 4	0
99	1	Input value level	Trigger edge of counter 1	0
99	2	Input value level	Trigger edge of counter 2	0
99	3	Input value level	Trigger edge of counter 3	0
99	4	Input value level	Spouštěcí hrana čítače 4	0
100	1	Input value	Current status of counter 1	0
100	2	Input value	Current status of counter 2	0
100	3	Input value	Current status of counter 3	0
100	4	Input value	Current status of counter 4	0
101	1	Input value multiplier	Multiplier of counter 1	1
101	2	Input value multiplier	Multiplier of counter 2	1
101	3	Input value multiplier	Multiplier of counter 3	1
101	4	Input value multiplier	Multiplier of counter 4	1
102	1	Input value divider	Divisor of counter 1	1
102	2	Input value divider	Divisor of counter 2	1
102	3	Input value divider	Divisor of counter 3	1
102	4	Input value divider	Divisor of counter 4	1
105	1	Temperature	Sensor temperature in tenths of Celsius	read only
105	2	Temperature	Processor temperature in tenths of Celsius	read only
106	1	Voltage (mV)	Battery voltage in mV	read only
109	1	SISA timeouts	Regular broadcasting period (sec)	1800
109	2	SISA timeouts	Period of A/D measurement (sec)	300
109	3	SISA timeouts	Receiving interval after transmission (50 ms)	4
109	4	SISA timeouts	Re-transmission period (50 ms)	1
109	5	SISA timeouts	Maximum number of re-transmissions	1
110	1	SLRF Channel	Frequency channel number	0
111	1	SLRF Hop Count	Maximum number of repeating message	3
114	1	SLRF Group Address	Module group (multicast) address	0
116	1	SLRF Repeater Flag	Switching of repeating mode	0
118	1	SLRF My Address	Module RF address	read only
122	1	SLRF CD Flag	Module transceiver mode (Carrier Detect)	1
123	1	SLRF Test flag	Switching of test broadcasting	0
124	1	SLRF Test timeout	Period of test broadcasting (50 ms)	20

In „Default” column there are default (factory) settings of the parameter. Colour marking of this field has following meaning:

- green colour - commonly used parameters that should be setup in reliance on the specific usage
- red colour - parameters that are not recommended to change
- grey colour - values that cannot be changed („read only”)

3.7 Structure of module data messages

The WM868-SI4-LP-H module communicates with other elements of the WACO RF network by data messages of the WACO SLRF communication protocol, which observes ISO/OSI communication model, its typical features are high effectivity and reliability, and enables huge variability of supported applications. A structure of individual layers of the WACO SLRF protocol is shown in the figure 19.




Figure 19: WACO SLRF protocol structure

Maximum total length of WACO SLRF data packet („packet”) is 63 Byte. The packets are bordered by preamble code and synchro-bits (6 Byte in total) at the beginning and by 16-bit checksum code (CRC) at the end.

Each data message contains 11 Byte long fixed header and data content („Payload”) with maximum length of 52 Byte. Packet header is very simple and contains only information that are necessary for routing of the packet (source and destination address, hop count, transaction ID) and a type of respective application („port number”). Payload data coding method is determined by application type. WACO SLRF data packet structure is shown in the figure 20.




Figure 20: Structure of WACO system data packet

The WM868-SI4-LP-H module is intended for reading of connected meters/sensors with pulse interface and broadcasting of current statuses („readings”) of the meters into the local WACO RF network in form of RF messages of „INFO” type. Transfer of INFO-messages is carried out by „SISA.TX” application (port number 37), that is one of „LPD Management” group of applications (LPD=Low Power Devices) used for data collection from battery powered modules. Battery powered „LPD devices” typically work in „active mode”, when the devices actively broadcast INFO-messages with preset broadcasting period and don’t expect confirmation of their receiving.

The WM868-SI4-LP-H module broadcasts current counter statuses of connected meters together with supplementary service information in sequence of **two** successive INFO-messages. **The first INFO-message** contains following variables:

- „**subtype**” (modification) of the module (OID=3)
- current **statuses of counters** (OID=100/1, 100/2, 100/3, 100/4)

The second INFO-message contains following variables:

- „**subtype**” (modification) of the module (OID=3)
- current status of module **system time** in seconds (OID=13)
- module **uptime** in seconds (OID=12)
- current status of module **battery voltage** in millivolts (OID=106/1)
- current status of module **processor temperature** in tenths of Celsius (OID=105/2)

Individual variables are coded into the data content of the message by using of ”NEP” proprietary coding system invented by SOFTLINK. In this system each type of variable has its own designation called ”OID” (Object ID), which determines meaning, character and data type of the variable. These variables, that could be used multiple times (as multiple inputs, temperatures, voltages...) must be used jointly with order number of the variable called ”Index”. „NEP coding table” is centrally maintained by SOFTLINK and it is available on the public WEB address [NEP Page](#). Preview of „NEP coding table” for coding of variables in the WACO system is shown in the figure 21.

ID	Typ	Index	ReadOnly	Název	Popis
1	T_STRING	✗	✓	OID_NAME	Device name
2	T_UNUMBER	✗	✓	OID_TYPE	Device type
98	T_UNUMBER	✓	✗	OID_IVALUE_TYPE	Input value type
99	T_UNUMBER	✓	✗	OID_IVALUE_LEVEL	Input value level
100	T_NUMBER	✓	✗	OID_IVALUE	Input value
101	T_NUMBER	✓	✗	OID_IVALUE_MULT	Input value multiplier
102	T_NUMBER	✓	✗	OID_IVALUE_DIV	Input value divider
103	T_NUMBER	✓	✗	OID_TEMPERATURE_LOW	Temperature low
104	T_NUMBER	✓	✗	OID_TEMPERATURE_HIGH	Temperature high
105	T_NUMBER	✓	✓	OID_TEMPERATURE	Temperature
106	T_NUMBER	✓	✓	OID_VOLTAGE	Voltage [mV]

Figure 21: Preview of „NEP coding table” for coding of variables in WACO system

If a receiver of ”INFO” messages from the module is „WACO collection unit” (see paragraph 1.2 „Module usage”), decoding of variables and their conversion into M-Bus system coding is performed by the collection unit.

If a receiver of ”INFO” messages from the module is any other application, it must be equipped with a decoding program for working with WACO communication protocol („WACO Driver”) that includes also NEP-decoder. Fixed general rules of NEP coding system enable decoding of any variable even if decoding system on the receiving side does not have all of them implemented. In this case the decoder extracts OID, index and value of the variable, but is not able to specify its meaning and measuring unit. WACO RFAN 3.x radio network analyzer has implemented a table of variables in the ”oids.xml” file. If the table is not up to date, it could receive messages with „unknown” variables that appear in the table of variables as records with incomplete description. In this case it is recommended to replace ”oids.xml” file by newest version that is available at producer of the analyzer.

View of both parts of WM868-SI4-LP-H module INFO message, as seen in „Packets” table of RFAN 3.x analyzer, is shown in the figure 22. Decoded values of message variables can be displayed in „tooltip” window by placing of cursor over the „Data” field of the message.

Index	Time [s]	ΔT [s]	RSSI	Dst Addr	Src Addr	Hop	Tid	Device	Port	Crypt	Ack	Length	Data
1	14:11.135	0.000	-75	Broadcast	ffedf41	3	2	End	SISA_TX			26	3f2106032168c064013100c064023100c064033100c064043100
2	14:11.242	0.107	-74	Broadcast	ffedf41	3	3	End	SISA_TX			27	3f21060321680d230f8e3f0c220396c06a01320d6ec069023200de
3	29:11.169	14:59.927	-79	Broadcast	ffedf41	3	4	End	SISA_TX			26	3f2106032168c064013100c064023100c064033100c064043100
4	29:11.169	0.000	-79	Broadcast	ffedf41	3	5	End	SISA_TX			27	3f21060321680d230f91c30c22070ac06a01320ecc069023200de

Message type: INFO
 Device subtype: 104
 Input value[1]: 0
 Input value[2]: 0
 Input value[3]: 0
 Input value[4]: 0

Message type: INFO
 Device subtype: 104
 System (s): 1020355
 Uptime (s): 1802
 Voltage [mV][1]: 3308
 Temperature[2]: 222

Figure 22: View of WM868-SI4-LP-H module INFO message received by RFAN 3.x analyzer

4 Operational conditions

This section of the document describes basic recommendations for transportation, storing, installation and operation of WM868-SI4-LP-H radio modules.

4.1 General Operation Risks

The radio modules are electronic devices power-supplied by internal batteries. The modules read counters or registers of the connected consumption meters or sensors. During their operation be aware mainly of the following risks:

4.1.1 Risk of mechanical and/or electric damage

The devices are enclosed in plastic boxes, so that the electrical components are protected from the direct damage by human touch, tools or static electricity. In normal operation no special precautions are needed, besides avoiding of the mechanical damage from strong pressure or shocks.

Special attention is required for signal cables that connect the radio modules with the meters or sensors. In operation it is necessary to ensure that the cables are not stressed by mechanical tension or bending. In case of damage of any cable isolation it is recommended to replace the cable immediately. If the module is equipped with a remote antenna on a coaxial cable, much attention should be paid for the antenna and the antenna cable as well. The minimum bending radius of the antenna cable with 6 mm diameter is 4 cm, for the antenna cable with the 2,5 mm diameter the bending radius is 2 cm. Violation of these bending parameters can lead to breach of homogeneity of the coaxial cable that can cause reducing of radio range of the device. Further it is necessary to ensure that the connected antenna cable will not stress the antenna connector of the device by tension or twist. Excessive loads can damage or destroy antenna connectors.

Installation of the module can be performed only by a person with necessary qualification in electrical engineering and at the same time trained for this device installation. It is recommended to lead antenna and signal cables as far from 230/50 Hz power cables as possible.

4.1.2 Risk of premature battery discharge

The devices are equipped with the long duration batteries. Battery life can be influenced by these factors:

- storage and operation temperature – in high temperatures the spontaneous discharging current increases, in low temperature the battery capacity reduces;
- frequency of radio-transmitting.

Modules are delivered with preset period of regular transmitting of info-messages as stated in the configuration table in section of this document and the battery life cycle is quoted for this period. If the transmitting period is significantly reduced, battery life will be proportionally shortened.

The battery life shortens also when the radio network is overloaded by the heavy radio traffic which causes the situation when each module has to wait in the active mode to catch the moment of „radio silence” to be able to send its message. Such situation can happen when the installation contains hundreds of WACO radio modules in the same frequency channel, or when there is a high number of repeaters installed, or when the traffic is loaded by external disturbing signal. However, these factors can be eliminated by the professional design of the WACO network topology and setting up of correct parameters (especially „Repeat”, „Repeat TimeOut”, „Rx TimeOut” and „WOR”) in accordance with producer’s recommendation.

4.1.3 Risk of damage by excessive humidity

Radio modules could be (as any other electronic devices) damaged by water, that could cause a short-circuit among some electronic elements or corrosion of the elements. Modules are enclosed in plastic boxes that are proof against squirted water and are suitable for indoor as well as outdoor installations. Correctly assembled plastic box protects the device against direct penetration of water, but it not protects properly against gradual penetration of humid air which can cause corrosion or damage by condensed water inside the box. Risks of damage of the device caused by penetration of excessive humidity can be eliminated by these precautions:

- install only modules that are correctly assembled, with undamaged box and undamaged rubber seal;

- in case of any doubt perform additional sealing of connection of both parts of the box and both cable bushings by silicon sealant;
- if higher grade of protection against humidity required (IP68), perform additional sealing of the module by high-adhesion silicon filling according to producer instruction (*). This treatment can be also ordered at manufacturer;
- install modules only to the sites where relative humidity exceed value of 95% only occasionally;
- install modules only to the sites where they can be squirted or sprayed by water only occasionally and only for a short time;
- in any case do not install modules to the sites where they can be dipped into the water.

(*) Do not open the module with additional sealing by silicon filling without serious reason. Switch the module on and perform its setting before this treatment. If there are necessary any changes in configuration, perform this changes via radio (if possible).

4.2 The condition of modules on delivery

Modules are delivered in standard cardboard boxes. The modules are commonly delivered with battery switched off. There is an exception in case the modules are delivered with additional sealing by silicon filling - in this case the modules are switched on.

4.3 Modules storage

It is strongly recommended to store the modules in dry rooms or halls, in the temperature interval (0 ÷ 30) °C. To prevent the unwanted discharging of internal battery it is recommended storing the modules with batteries disconnected and activate the battery during mounting (with exception of modules with additional sealing by silicon filling - see paragraph 4.2).

4.4 Safety precautions

Warning! Mechanical and electrical installation of the WM868-SI4-LP-H module can be provided only by a person with necessary qualification in electrical engineering.

4.5 Environmental protection and recycling

The equipment contains non-rechargeable lithium battery. It is necessary to remove battery before module disposal and dispose battery separately in compliance with the dangerous waste disposal rules. Damaged, destroyed or discarded devices cannot be disposed as household waste. Equipment must be disposed of in the waste collection yards, which dispose electronic waste. Information about the nearest collection yard can be provided by the relevant local (municipal) authority.

4.6 WM868-SI4-LP-H module installation

The WM868-SI4-LP-H modules are enclosed in plastic casings with an IP65 degree of protection. The casing consists of two parts:

- the module base with the printed circuit board and cable bushings;
- cap of the box covering printed circuit board, with mounts for attaching of the module to a pad.

View of the WM868-SI4-LP-H module dismantled into individual components and detailed view of the module's printed circuit board from the elements side can be seen in the figure 23.

In the picture of module printed circuit board there are some important components marked by colour rectangles: configuration connector (red), battery switch (yellow), input signal clamps (blue) and antenna connector (green).

The case of WM868-SI4-LP-H module consists of two parts:

- module base with the printed circuit board attached. It is the where the cable bushings are placed;
- box cap that covers the printed circuit board, with mounts for attaching of the module to the wall or other construction element




Figure 23: Detailed view of the WM868-SI4-LP-H module

When mounting the device follow these instructions:

- attach the module to a suitable firm object (wall, pipe) by two screws or by a clamping tape. There are mounts by the box sides for the attachment. The recommended position of the mounted module is in the way that the base is down, cable bushings are facing to the floor;
- unscrew the screws on the sides of the module base (right beside the cable bushings), loosen the cap of the module and slide the base out of the cap;
- pull the cables with the pulse outputs from the consumption meters through the cable bushings (**) and connect the individual conductors to the input clamps of the module. The scheme of deployment and polarity of individual clamps is glued inside on the cap of the box. Make sure that the meters are connected to the relevant inputs according to the project materials or write down the diagram of individual connections;
- connect the local antenna (stick or rod type) or an antenna cable from a remote antenna into the antenna connector (coaxial connector on the printed circuit board beside the input clamps). Pull the antenna or the antenna cable through the cable bushings that is just right opposite to the antenna connector;
- switch-on battery by switching of both of the micro-switches („jumpers”) placed on the PCB beside the configuration connector into the „ON“ position. Some modifications of the module could be equipped with a pair of simple shortening pins, that should be short-circuited by shortening connector;
- perform an elementary module diagnostics and alternatively go through the module configuration (setting of parameters) with using of configuration cable as described in chapter 3 „Module configuration”. In case the module has been fully pre-configured in the preparatory phase of installation, at least check and set-up input/output values to ensure that the information sent in the radio-messages will be correct;
- tighten the nuts on the cable bushings to seal them and protect the cables from unwanted pulling out of the clamps;
- insert the base back into the cap and fix with screws. For the mounting in a humid environment it is recommended to apply silicone sealant on the outer perimeter of the seating edge of the base before screwing the box back together;
- if the internal rules or the mounting process needs the antifraud seal to be installed (as the protection from the unwanted influencing), stick the antifraud seal across the joint between the two parts of the box.

(*) **ATTENTION!** If the module is sealed by additional silicon filling with IP68 degree of protection do not open its casing during the installation! Meter outputs can be connected to appropriate wires of the input cable (that had been connected to the module before silicon filling) and configuration could be performed by radio or by using of an optical converter USB-IRDA.

If the module is rated in IP65 or IP68 degree of protection, this declaration is valid only under condition of the proper mounting and sealing. When assembling the modules with IP68 degree of protection that will be placed in the humid environment, it is necessary to follow these rules:

- both cable bushings must be properly sealed;
- the joint of both parts of the box must be properly sealed by original rubber sealing).

After the mounting, write down the counter values of all consumption meters connected to the module into the mounting sheet and alternatively once again check out the module's functionality and the correctness of output values (which must correspond to consumption meter mechanical counters). Test the module functionality by „end-to-end” method, that means by checking of the readings directly in the central system of remote reading.

Follow the consumption meter manufacturer's instructions for determination of the length of the connection cables between the consumption meters and the radio modules.

When locating installation site, selecting antenna type and antenna position it is necessary to take into account conditions for radio signal propagation in the area of installation as well as protection of the device against possible mechanical damage. The radio-signal conditions can be estimated empirically on the base of previous experience, or examined by measuring of the signal strength by the reference transmitter/receiver.

4.7 Module and meter replacement

When there is necessary to replace the module due to the module failure or due to battery discharging follow this procedure:

- check the antifraud seal before dismantling – the antifraud seal damage must be solved according to the internal rules of the customer/project;
- unscrew two screws on the sides of the module base (beside the cable bushings), loosen the cap of the module and slide out the base from the cap;
- disconnect the cables from the consumption meters from the input clamps, alternatively disconnect the cable of the external antenna from the antenna connector;
- by switching of both of the micro-switches („jumpers”) placed on the PCB beside the configuration connector into the „OFF“ position (or replacing of shortening connector from shortening pins) disconnect the module from the battery power supply;
- loosen the fixing screws (or clamping tape) that hold the module on the wall, pipe or other pad and dismantle the cap;
- put both parts of the module back together by screwing the cap together with base (*). Mark the module visibly as „defective”, alternatively you can fill in the form (mounting report) about the module replacement;
- install a new module in the same way as described in paragraph 4.6 above. Pay attention to the correct connection of the input cables (must be the same inputs as they were on the original module) and set up the relevant configuration parameters, namely broadcasting period and input/output values.
- write down the serial number and seal number of the module, alternatively also actual statuses of counters of connected meters;
- if possible, arrange making of all appropriate changes in the database of the remote reading system immediately.

(* **CAUTION!** *The type label with RF-address and serial number of the module is always on the cap of the module so the base and the cap of the module must always be one whole unchangeable unit. Always pay attention to the completing of the correct cap with the correct base of the module, that is the reason why it is always necessary to replace the whole module – the base and the cap together. The correct module completion can be checked out according to the auxiliary label with the RF-address glued on the PCB (RF-address on the PCB must correspond with the RF-address on the cap of the module).*

When there is necessary to replace a consumption meter connected to the module due to the meter failure, expired metrology period or for any other reason, follow this procedure:

- check the antifraud seal before dismantling – the antifraud seal damage must be solved according to the internal rules of each customer/project;
- if the module is sealed by additional silicon filling with IP68 degree of protection do not open its casing! Disconnect replaced meter from the input cable and connect new meter to the same wires;
- if the module is in common IP-68 design, unscrew two screws on the sides of the box (beside the cable bushings), loosen the cap of the module and slide out the base from the cap;
- disconnect the cables from replaced consumption meter from the input clamps, replace the consumption meter and connect its cable back into the input clamps;
- perform setting of input/output values of the relevant input according to the instruction in the chapter 3 „Module configuration”. Check out the correctness of output values (which must correspond to consumption meter mechanical counters) by checking of the readings directly in the remote reading system.
- fill in the required documentation for the meter replacement (mounting sheet), precisely write down the value of the mechanical counter of the new meter;
- cover the module and, if needed, apply the sealant according to the instructions in paragraph 4.6. Alternatively wait for the first reading and cover the module afterwards.

(* **CAUTION!** *The new meter might require a different setting of module's input/output even if the meter is the same type and manufacturer. Conversion constants can differ from each other even in various modifications of the same type of the meter.*

4.8 Module dismantling

When dismantling, open the module, disconnect cables and dismantle the cap from the wall, pad or pipe. Switch the battery off and put the module parts back together (put the cap on the base of the module). After the dismantling mark the module as „dismantled” and fill in the relevant documentation, prescribed for this situation by the internal rules. If possible, arrange deactivation of the module in the database of remote reading system immediately.

4.9 Functional check of the module

After putting the module into operation (or after each repair and replacing of the module) it is recommended to check module basic functionality as follows:

- check broadcasting functionality by RFAN 3.x analyzer in ”Packets” or ”Radar” mode (according to the analyzer documentation) with using of „test broadcasting” function described in the paragraph 3.5.6 „Setting of test broadcasting”.
- perform overall check of transmitter and receiver functioning by testing of remote configuration via radio with using of RFAN 3.x analyzer (i.e. reading of any module’s parameter by ”GET” command as described in chapter 3.2 „Configuration of the module via radio”);
- check implementation of the module within remote reading system (including correctness of setting of the central database) by checking of correctness of the data rendered by the module.

4.10 Operation of the WM868-SI4-LP-H module

When working in the **automatic reading system** the WM868-SI4-LP-H module performs remote reading of the meters and sensors and broadcasts measured values fully automatically. The greatest risks of module service breakdown are commonly caused by human activities within the installation site, especially risk of mechanical damage of the module by improper handling around the installation site, or by temporary or permanent shading of the antenna by metal object (e.g. due to building operations). The typical result of the damage is full lost of connection with the module. Replacing or shading of the module (or its antenna) can cause decreasing of radio signal strength with negative influence on the reliability of remote reading, or full interruption of radio connection.

To eliminate these risks, it is recommended to pay close attention to selection of the installation site and choice of antenna and antenna location so that to find appropriate compromise between qualities of signal and the level of risk of mechanical damage of the module or antenna. It is necessary to carry out the installation carefully with using of high-quality cables and mounting components.

To prevent an unexpected breakdown, it is recommended to perform regular monitoring of all broadcasting data, i.e. readings, processor temperature and battery voltage. If some of the parameters goes beyond the common steady value, it is recommended to contact the installation site caretaker and ask for the potential cause of the anomaly or perform the physical check on the installation site.

When working in the **„Walk-By” reading system** the risks of the mechanical damages are the same as for the on-line reading system and can be eliminated in the same way. Correctness of read data can be checked only during the walk-by reading, when the data are available. If there is any anomaly in the data, it is recommended to perform a visual inspection of installation site immediately and check correctness of read data by comparing of their values with values of mechanical counters.

The risk of **premature battery discharge** could be eliminated by respecting the instructions described in paragraph 4.1.2.

5 Troubleshooting

5.1 Possible causes of module failures

If during operation of WM868-SI4-LP-H module some anomaly, malfunctions or other troubles are recognized, the possible causes of the failures can be classified by following categories:

5.1.1 Power supplying failures

The module is supplied by electrical power from the long-life internal battery. Approximate battery life is specified in paragraph 1.2 „Modul usage”. Battery life can be negatively influenced by circumstances that are described in detail in paragraph 4.1.2 „Risk of premature battery discharge”.

Low battery power becomes evident as irregular drop-outs of signal reception from the module, finally the radio connection with the module completely fails.

Battery is soldered into the printed circuit board of the module and the module has to be disassembled for its replacement. Battery replacement can be performed only by qualified and experienced person. Soldering of battery by unskilled person can cause irretrievable damage of the module. There are only top-quality batteries used in the wacoSystem modules, that have been carefully selected and properly tested. In case of battery replacement by user the new battery parameters should meet same technical requirements (type, capacity, voltage, current load, auto-discharging current...) as the original battery. It is strongly recommended to use for replacement same type of battery as used in production.

5.1.2 System failures

As „system failure” are considered mainly failures of module’s processor, memory, internal supplying or any other failures that cause a complete breakdown of the device. If module’s battery has correct voltage with no signs of discharging and the device still does not communicate through its configuration port and does not respond to any commands and this status will not change even after module’s restart (by switching off and switching on its battery), the system failure probably occur. Perform the replacement of the module according to the instructions in paragraph 4.7 and check functionality of the new module. If the new device works properly, label the original module as „defective” and fill in the appropriate documentation prescribed by internal rules for this case.

5.1.3 Failures of communication with meters

Failures of pulse signal transfer from the consumption meters to the correspond module inputs typically appear as „zero consumption” of the meter even though the consumption of the meter is evident, or generally, meter status from remote reading is different than meter status shown in meter’s mechanical counter. In this case try to proceed with troubleshooting of the connection with meters in following steps:

1. Visually check the meter and connecting cable between meter and radio-module, especially whether the meter’s pulse generator is correctly mounted on the meter (if it is removable) and whether the meter or cable are not damaged;
2. in case of any doubt check the functionality of cable connection by ohm-meter. If there is a problem with reliability of the connection, or the cable is evidently damaged, replace the cable immediately;
3. check whether the cable is correctly associated with the module input (correct port number, correctness of polarity - if required by meter producer);
4. Visually check if there are not placed any objects or devices radiating a magnetic field (for example a device for water treatment with magnet, electrical installation. . .) around the consumption meter. The pulse generators of some types of the consumption meters are very sensitive to the magnetic field presence. If such device is detected, it must be removed or there must be taken necessary measures to eliminate the magnetic field influence on the pulse generator of the consumption meter. To find more about the influence of the magnetic field on a particular consumption meter, you must follow its manufacturer instructions;
5. if there is some possibility of measuring metering pulses, make sure that the meter generates the pulses properly and that these pulses lead up entirely to the radio module input;
6. correctness of generating and transfer of metering pulses can be alternatively checked by short-circuiting of the cable on the meter side. If after each short-circuit the status value of the module’s counter goes up, the module and cable are probably correct, and the trouble is probable caused by meter or by its pulse generator;

7. if the module doesn't read the data even the metering pulses are provably brought to the correct radio module input, check the pulse counter parameter settings (counter mode, trigger edge) according to the paragraph 3.5.5 „Internal Counter Setting Commands”. In case the setting is correct, the problem is the most probably in the malfunction of the radio module. Replace the module following the instructions in the paragraph 4.7.

If the module register „false” pulses (consumption registered by remote reading is significantly higher than consumption registered by mechanical counter) and setting of the counter to „slow” mode has not solved the problem, the failure could be caused either by too long or poor-quality cable or strong local disturbance (or combining of these two circumstances). In this case replace the cable for high-quality shielded one or make changes in the installation to shorten the cable.

In case of unstable data transfer from connected sensors the signs of failure are very similar to the troubles with pulse meters - the wrong indication of measured data from sensors. Troubleshooting of this failure is similar with troubleshooting of pulse meters:

1. visually check the sensor and connecting cable between sensor and radio-module for any damage;
2. check whether the cable is correctly associated with the module input (correct port number, correctness of polarity - if required by sensor producer);
3. visually check if there are not placed any objects or devices around the sensor that can influence its functioning;
4. check correctness of the sensor input by short-circuiting of the cable on the sensor side. If after each short-circuit the value of the module's counter changes, the module and cable are probably correct, and the trouble is with high probability caused by sensor;
5. if the module doesn't register the changes of sensor status even though the changes are provably brought to the correct radio module input, check the counter parameter settings (counter mode, trigger edge) according to the paragraph 3.5.5 „Internal Counter Setting Commands”. In case the setting is correct, the problem is the most probably in the malfunction of the radio module. Replace the module following the instructions in the paragraph 4.7.

5.1.4 Transmitter and receiver failures

If the module is powered by correct voltage, the module communicates through the configuration port, responds to the configuration commands but the radio-messages from the module are still not received steadily, the possible reason of the trouble can be a failure of transmitting or receiving of radio signal. The typical indication of transmitting or receiving failures is state of „partial” functionality, that have following external signs:

- the module transfers data only from certain elements of the radio-network, data from other elements are not transferred;
- certain elements of the network do not receive data from the module;
- data from certain elements of the network are incorrect or incomplete;
- there are numerous breakdowns in the data communication (sometimes the data pass through the module, sometimes not).

All above described troubles could have on common ground, which is unreliability of radio-communication caused by one of these reasons:

- incorrect setting of transmitter parameters, mainly frequency channel, maximum number of re-translations, or transmitting power;
- permanent or occasional blocking of radio signal caused by construction works or any construction changes within the premises, or by operation around the installation site (moving of machines, cars, etc.);
- permanent, periodical or occasional interference (jamming) of radio signal from external source (another radio system in the same frequency band, or industrial disturbance).
- low level of transmitting signal caused by wrong setting or failure of transmitter;
- low level of receiving signal caused by wrong setting or failure of receiver;
- low level of transmitting and receiving signal caused by damage of antenna or antenna cable (if external antenna used).

If above described indications of unreliable radio-communication become evident, proceed with troubleshooting of the malfunctioning in following steps:

- visually check surrounding of the installation site to find out if there are any changes that can influence radio signal (e.g. new objects, things, machines...). If there are such negative circumstances, solve the trouble by reorganization of the object or by redesign of radio network;
- visually check an external antenna and antenna cable (if used), possibly replace these elements for the spare ones with proven functionality;
- check correctness of module settings, especially setting of radio parameters as described in paragraph 3.6 and perform the check of module overall functionality as described in paragraph 4.9;
- if there are breakdowns in communication with some specific element of the network, check functionality of that element according to the respective documentation;
- replace the module according to the paragraph 4.7 and perform the setting and check of overall functionality off the new module after that;
- if the module is not properly working even after its replacement for proven device and equipment, the trouble can be caused by local interference (jamming) from external source. Another possible reason could be an unsuitable setting of some configuration parameter that has not been discovered. In this case ask for your supplier, producer, or other experienced person for some form of assistance.

Appropriate level of transmitting power can be checked by comparing of its signal strength with the reference signal from another module (modules) under comparable circumstances, for example with using of signal analyzer or testing receiver placed to the suitable spot. If the signal strength is similar to the signal of reference transmitter, then the module's transmitting power is adequate, and the reason of troubles could be in insufficient signal strength on the receiving side. Attenuation of the signal can be caused by making of some change in module installation site (e.g. turning of antenna or placing of some object nearby, installation of iron bars, rack or shelves...) or similar changes in the installation site of receiver (GateWay). This kind of troubles can be solved by redesign of the radio network in order to secure sufficient signal reception (that means changing of antenna for better type, moving of antenna or whole device etc.).

5.2 Troubleshooting procedure

To identify a reason of device failure or any anomaly in its operation follow this procedure:

1. The module communicates normally, readings from meters/sensors are available (in on-line or in walk-by mode), but data from some meters/sensors are apparently incorrect. In this case it is recommended to check functionality of the module subsystems in following order:
 - check correctness of central application configuration related to the meter/sensor, especially correctness of its ID, address and association of the meter/sensor with right port of reading module. Check correctness of counter initial value;
 - check functionality of receiving pulse signals on the module's input as described in paragraph 5.1.3 „Failures of communication with meters”.
2. Data from the module are coming irregularly, with periodical breakdowns. In this case it is recommended to check functionality of the module subsystems in following order:
 - check functionality of the transmitting and receiving of the radio-signal as described in the paragraph 5.1.4 „Transmitter and receiver failures”;
 - check functionality of internal battery as described in the paragraph 5.1.1 „Power supplying failures”;
 - check functionality of the device that receives messages from the WM868-SI4-LP-H module (local gateway, master, collection unit...) according to the appropriate documentation.
3. No data are available from all meters/sensors connected to the WM868-SI4-LP-H module. In this case it is recommended to check functionality of the module subsystems in following order:
 - check correctness of setting of the module in the central system database;
 - check functionality of power supplying as described in the paragraph 5.1.1 „Power supplying failures”;
 - check functionality of the system as described in the paragraph 5.1.2 „System failures”;
 - check functionality of the transmitting and receiving of the radio-signal as described in the paragraph 5.1.4 „Transmitter and receiver failures”.

NOTE: WM868-SI4-LP-H module is a reliable device with relatively simple and resilient construction, so that any possible failure of the device is very likely caused by external circumstances, especially mechanical damage, excessive humidity, discharging of internal battery, or voltage pulses induced to the input cables. After each replacement of the module caused by its failure it is recommended to check the root cause of the failure and take necessary measures to eliminate any persisting troubles.

6 Additional information

This manual is focused on description, parameters and configuration options of radio modules WM868-SI4-LP-H of the WACO RF system, operating in the 868 MHz band, that are a part of the Softlink's **wacoSystem** product family. More information about all WM868 (WACO), WB169 and WB868 (Wireless M-BUS), or WS868 (Sigfox) series of the modules can be found on the manufacturer website:

www.wacosystem.com

www.softlink.cz

If interested in any additional information related to application of radio modules of WM868, WB169, WB868, or WS868 series or other manufacturer's equipment for telemetry and remote reading of consumption meters, feel free to contact the manufacturer:

SOFTLINK s.r.o., Tomkova 409, 278 01 Kralupy nad Vltavou, Czech Republic

Phone.: +420 315 707 111, e-mail: sales@softlink.cz, WEB: www.softlink.cz.